

Installation Instructions

Frymaster (Built-In) FootPrint Pro Filtration System

SuperSorb[®]
CarbonPads

Getting the most out of your frying program

- 1)** Open the fryer doors and pull the filter pan out. Remove weight ring, but leave the screen in place at the bottom of the well.



- 2)** Insert the F-33 (14.75" x 22") or F-54 (14.125" x 21") CarbonPad into the pan with the bumpy side up. Be sure the CarbonPad is centered over the well.



- 3)** Insert the new Frymaster hold down bar, 810-2909 as shown, or 810-3946 Hold down ring and press it firmly into place. Insert crumb catcher, remember to scrape the crumbs off the CarbonPad for multiple fryer filtrations.



FILTERCORP

9805 NE 116th Street
PMB A-200
Kirkland, WA 98034
USA

Toll Free: (800) 473-4526
Telephone: (425) 820-4850
Fax: (425) 820-2816
Web: www.filtercorp.com



www.filtercorp.com